

**MINCO Temptran™**  
**4-20 mA Current Transmitter**

**Model TT321**

**INSTALLATION INSTRUCTIONS**

---


**Installation:**

Ambient temperature of the Temptran should stay between 0 and 50°C (32 and 122°F). Mount with a #6 machine or #8 self-tapping screws.

Connect the Temptran as shown, observing +/- polarity of the current loop. Maximum DC supply voltage = 35 VDC. The RTD connections have polarity, refer to drawing below for correct connection. For the RTD, good connections are a must; a few ohms of resistance in the connection can cause an error of several degrees.

The Temptran has been factory-calibrated for its marked temperature range or else for a specific RTD. Do not change its zero or span adjustments.

**Wiring Diagram**



**How it works:**

The Temptran converts an RTD's (resistance temperature detector's) resistance signal into a current proportional to the RTD's temperature. The current changes according to the range marked on the Temptran: 4mA at the lowest temperature of the range, rising to 20mA at the top of the range. The leads that supply power also carry the current signal.

**MINCO** PRODUCTS, INC.

7300 Commerce Lane, Mpls., MN 55432

Telephone: (763) 571-3121 FAX: (763) 571-0927

©2003 Minco Products, Inc.