

# C325 Variac Wiring Diagram

## AC Wiring

### Variable AC Autotransformer to Adjust Heater Wattage

(external SSR's are capable of handling 10-50 amps)

