
MINCO TT274

2-wire Temperature Transmitter

Installation and Operating Instructions





7300 Commerce Lane/Minneapolis, Minnesota 55432-3177 U.S.A. Telephone: (763)571-3121 / FAX: (763)571-0927

Description


Model TT274 is a 2-wire temperature transmitter for T/C's (thermocouple thermometers). The TemptranTM converts the T/C's signal into a 4 to 20 mA current. The current changes according to the range marked on the Temptran: 4 mA at the lowest temperature of the range, rising to 20 mA at the top of the range. The leads that supply power also carry the current signal.

Installation

Locate the Temptran near the T/C, in an area where the ambient temperature stays between -40 and 85 °C (-40 and 185 °F). If calibration is necessary, set dip-switches before attaching to DIN rail.

Connect the Temptran as shown below, observing the \pm polarity of the current loop and T/C connections. Maximum DC supply voltage = 45 VDC. The T/C connections for the Temptran in the wiring diagram below must be connected as shown or the transmitter will not function properly.

Wiring Diagram



Calibration


Determine thermocouple type, either K or J. Select desired Zero (4 mA) temperature and Span (20 mA- 4 mA) range from the tables below. The Zero temperature must be within -50 to 150 °C, and the Span range (20 mA temp. - 4 mA temp.) must be within 150 to 1200 °C for a type K thermocouple and 125 to 850 °C for a type J thermocouple. For example, for a -25 to 200 °C temperature range and type K thermocouple, the Zero temperature is -25 °C and the Span range is (200-(-25)) = 225 °C. According to the tables, switch positions 1 and 5 would be ON.

Zero (4 mA) coarse adjust			
	Thermocouple Type		
Switch Position	K	J	
1 ON	Х		
1 OFF		Х	
2, 3, 4 OFF	-50 to 0 °C (-58 to 32 °F)		
2 ON 3, 4 OFF	0 to 50 °C (32 to 122 °F)		
3 ON 2, 4 OFF	50 to 100 °C (122 to 212 °F)		
4 ON 2, 3 OFF	100 to 150 ℃ (212 to 302 ℉)		

Span (20 mA - 4 mA) coarse adjust		
	Thermocouple Type	
Switch Position	К	J
5 ON	150 to 225 °C	125 to 170 °C
6-9 OFF	(302 to 437 °F)	(257 to 338 °F)
6 ON	225 to 325 °C	170 to 250 °C
5, 7-9 OFF	(437 to 617 °F)	(338 to 482 °F)
7 ON	325 to 475 °C	250 to 360 °C
5,6,8,9 OFF	(617 to 887 °F)	(482 to 680 °F)
8 ON	475 to 675 °C	360 to 515 °C
5-7, 9 OFF	(887 to 1247 °F)	(680 to 959 °F)
9 ON	675 to 925 °C	515 to 690 °C
5-8 OFF	(1247 to 1697 °F)	(959 to 1274 °F)
	925 to 1200 °C	690 to 850 °C
5-9 OFF	(1697 to 2192 °F)	(1274 to 1562 °F)

2. Set dip-switches per values selected from tables.

- 3. Connect a power supply of 24 VDC, and a digital milliammeter (5-1/2 digit preferred) as shown in figure 1, or use a loop calibrator instead of the DC supply and milliammeter.
- 4. Connect a thermocouple simulator with cold junction compensation to the input of the transmitter.



- 5. Set thermocouple simulator to simulate the 4 mA temperature. For the given example, the simulator should be set to -25 °C.
- 6. Adjust ZERO potentiometer on the transmitter until the meter reads 4 mA.
- 7. Set thermocouple simulator to simulate the 20 mA temperature. For the given example, the simulator should be set to 200 °C.
- 8. Adjust SPAN potentiometer on the transmitter until the meter reads 20 mA.
- 9. Repeat steps 5-8 until no further adjustment is necessary.


Warranty

Items returned within one year from the date of sale, transportation prepaid, which Minco Products, Inc. (The "Seller") reasonably determines to be faulty by reason of defective materials or faulty workmanship will be replaced or repaired at the Seller's discretion, free of charge.


This remedy is to be the sole and exclusive remedy available to the buyer in the event of a breach by the Seller. Items that show evidence of mishandling or misapplication may be returned by the Seller at the customer's expense.

Furthermore, the Seller is not to be held responsible for consequential damages caused by its product except as required under Minnesota Statutes, Section 336.1-719 (3).

This warranty is expressly in lieu of any other expressed warranty or implied warranty of merchantability or fitness for a particular purpose, and of any other obligations or liability on the part of the Seller or its employees or agents.



Dimensions: All dimensions are in inches (millimeters)



When quality and performance are as important as price, call...

MINCO PRODUCTS, INC.

7300 Commerce Lane/Minneapolis, Minnesota 55432-3177 U.S.A Telephone: (763)571-3121 / FAX: (763)571-0927 ©2001 Minco Products, Inc.

F:\MOD\TT274\LIT\897MN.DOC 4/7/11 bmp Stock #360-00078