

**MINCO Temptran™**  
**4-20 mA Current Transmitter**  
**TT355**

**INSTALLATION INSTRUCTIONS**

---


**Installation**

Ambient temperature of the Temptran should stay between -25 and 85°C (-13 and 185°F). Mount near the thermistor (sensor) with a #6 machine or #8 self-tapping screws.

Connect the Temptran as shown, observing +/- polarity of the current loop. Maximum DC supply voltage = 35 VDC. The thermistor connections have polarity.

The Temptran has been factory-calibrated for its marked temperature range or else for a specific thermistor. Do not change its zero or span adjustments.

**Wiring Diagram**



**How It Works**

The Temptran converts a thermistor resistance signal into a current proportional to the thermistor's temperature. The current changes according to the range marked on the Temptran: 4mA at the lowest temperature of the range, rising to 20mA at the top of the range. The leads that supply power also carry the current signal.

**MINCO** PRODUCTS, INC.

7300 Commerce Lane, Mpls., MN 55432

Telephone: (763) 571-3121      FAX: (763) 571-0927

©2001 Minco Products, Inc.

Doc. #2612424 (A)