

SPI 00-0598 Mounting Thermofoil™ Heaters with #12 Pressure-Sensitive Adhesive

Overview

Minco #12 pressure-sensitive adhesive (PSA) is a silicone based adhesive with thermosetting properties when properly cured. Minco #12 PSA has low adhesion to fingertips. Initial tack or adhesion is low, but optimal adhesion is achieved over time as the adhesive gradually wets-out to the heat sink surface.

Warranty

Minco warranties #12 PSA for three months after the Do Not Ship After (DNSA) date on the part's packaging barcode label. The shelf life of #12 PSA is three months when stored at 21°C (70°F) or below and 50% relative humidity. After this time, the PSA retains its adhesive properties, but it may adhere to the backing making the backing very difficult to remove.

Surface Preparation

Make certain that the surface to which the Thermofoil™ heater is to be bonded is clean, dry, and dust-free. An etched or otherwise slightly roughened surface usually permits the best bond. Cleaning solvents such as acetone, toluene, or xylene may be used, depending on the surface.

Mounting Procedure

Follow the steps in the table below to mount heaters with #12 PSA.

Step	Action
1	Remove the protective release backing from the adhesive side of the heater. Tweezers are recommended for lifting a corner of the release backing. A quick sharp continuous pull of the release backing at an angle of at least 120° gives the best results. Do not stop until the backing is completely removed. WARNING: Do not touch the adhesive or allow foreign materials to adhere.
2	Carefully position and apply the heater to the desired surface, making certain that firm, even pressure is applied to the entire bonding area. Try to avoid air entrapment while installing. Hand pressure is sufficient to result in good adhesion at normal room temperature. To achieve maximum bond strength, allow 72 hours wet-out time. If placing a heater onto a cylindrical surface with a diameter smaller than 6", it may be necessary to wrap heater with high-temperature tape in order to keep it in contact with the heat sink.

Continued on next page

DR: MV 1/15/10 QA ENG: KR 1/14/10 APP: MK 1/13/10	 7300 Commerce Lane Minneapolis, MN 55432 U.S.A. Phone: 763-571-3121 Fax: 763-571-0927 www.minco.com	Standard Process Instruction 00-0598
		ECO #1313195 Rev. –
		Page 1 of 2

Mounting Thermofoil™ Heaters with #12 Pressure-Sensitive Adhesive, Continued

Mounting Procedure (continued)

3	The heater is now ready for use. However, for best adhesion, steps 4 through 8 are recommended.
4	Press the installed heater into close contact with the heat sink surface at room temperature using a rubber roller or equivalent. Apply pressure starting at the center of the heater and roll to each outer edge to remove any entrapped air.
5	Place the installed heater with part in an oven set at approximately 150°C (300°F) for 10 to 15 minutes to thermally set and cure the adhesive film.
6	Steps 4 and 5 are especially recommended in applications where optimum adhesion is required for a long time. In either case, allow 72 hours wet-out time.
7	If the heater is mounted on a curved surface, best results can be obtained by applying a fillet of adhesive (Minco #6 RTV cement) between all exposed edges of the heater and the surface of the mating part.
8	If the mounted heater is to be operated in a vacuum environment, it is recommended that the heating indicated in step 5 be performed in a vacuum chamber to ensure removal of all entrapped air. The temperature should be set at least as high as the operating temperature, but not to exceed 175°C (350°F).

We believe this information to be reliable, but the customer must assume responsibility for heater performance in the intended application. **Minco accepts no liability beyond our standard warranty for consequences of improper installation and/or heater or adhesive failure.**

If any questions or problems occur, contact your Minco sales representative or the factory for assistance.